

Novel 3-D Differential Phase Contrast Imaging

Lambertus Hesselink, Yao-Te Cheng, Juan
Maldonado, Max Yuen, Jeff Wilde, Yuzuru
Takashima, Ludwig Galambos, Chengzhang Li,
Piero Pianetta, Fabian Pease

Departments of Electrical Engineering, Applied
Physics and Materials Science and Engineering

Stanford University

October 23, 2013


Acknowledgments

- We are grateful for support from the DHS S&T under grant:
HSHQDC-12-00002


Content

- Motivation
- Differential phase contrast imaging
- Photoelectron X-Ray source array (PeXSA)
- Summary

Introduction: Problem Statement




H. Martz, C. Crawford, Explosives detection in aviation applications using CT, LLNL, June 2010




- Improve discrimination through:
 - Improved data collection by measuring additional material's parameters:
 - Phase in addition to density and effective atomic number
 - Better 3-D reconstruction data

X-ray Differential Phase-Contrast Imaging

Differential phase contrast imaging



Transmission only



Differential phase contrast image




Pfeiffer et al., Nature Phys.. (2006)

Challenges:


- Need high aspect-ratio ($> 100X$) amplitude grating for high energy ($> 100 \text{ keV}$) X-ray design.

Experimental Schematic




- Incoherent, polychromatic source is made partially coherent by grating G0.
- G1 and G2 form a phase grating/amplitude grating interferometer analyzer pair.
- G0-G2 distance = 1.3m, G1-G2 distance 0.315m, G0=19um, G1=9um, G2=6um.
- Phase contrast signal is detected at the digital flat panel detector.
- X-ray parameters: 60kVp, 10mA, 7.5pps. Detector: 1x1 0.5pF Gain 2

Photos of the Setup



G0, on x-y stage




G1, on x-y and tilt/rotation stage
G2, on x-y-z and tip/tilt/rotation stage+ pico motor drive

X-ray Talbot Interferometry

- Uses Talbot effect for G1 and G2 gratings.
- Moiré Pattern detection at detector.
- Partial Coherence needed, G0 provides this via van Cittert-Zernike Theorem (Think Ducks).
- G1 can be Phase or Amplitude.
- Works with polychromatic sources.

The Talbot Effect



$$E(x, z) = C \int e^{i \frac{k}{2z} (x-x')^2} E(x', 0) dx'$$

$$E(x, 0) = T(x) = \sum_n a_n e^{i \frac{2\pi}{p_0} nx}$$

$$E(x, z) = C \sum_n a_n \int e^{i \frac{k}{2z} (x'-x)^2} e^{i \frac{2\pi}{p_0} nx'} dx'$$





$$E(x, z) = C' \sum_n a_n e^{i \frac{2\pi}{p_0} nx} e^{-i \frac{\pi \lambda z}{p_0^2} n^2}$$

$$2\pi m = \frac{\pi \lambda z}{p_0^2}$$





$$z = m z_T$$

$$z_T = \frac{2p_0^2}{\lambda}$$


X-ray Absorption, DPC, and Dark Field Contrast Images of Empty Cuvette



X-ray Absorption, DPC, and Dark Field Contrast Images of Water + Cuvette




Principal Component Analysis




Squared area shows in next figure

Principal Component Analysis




X-ray Differential Phase-Contrast Imaging


Differential phase contrast imaging



Transmission only



Differential phase contrast image



Pfeiffer et al., Nature Phys.. (2006)

Problems:



- Amplitude grating G_0 blocks $> 75\%$ of incident X-rays (for spatial coherence).
- Need high aspect-ratio ($> 100X$) amplitude grating for high energy ($> 100 \text{ keV}$) X-ray design.

Solution

Optically Driven Patterned X-ray Source

Photoelectron X-ray Source Array (PeXSA)

We can reduce the wasted X-ray power > 4X and replace the tricky high aspect ratio amplitude grating




A spatial light modulator now generates the optical pattern
... hence the e-beam pattern
... hence the X-ray pattern
 G_2 grating does not need to move!

Ongoing research



Photoelectron Source

UV activated intraband states in CsBr







Use UV to activate intra-band states first.

Photoelectron X-ray Source Array




PeXSA Setup



Laser input with lead enclosure

Photoelectron Excited X-ray

Transmission W target, Laser power 5 mW, V_{bias} 10 kV-30 kV



Summary

- DPC measurements provide richer detection signatures
 - *More work to be done to determine effectiveness within cluttered bag*
- *Photo Electron X-ray Source Array (PeXSA) enables simpler and more sensitive DPC system with large FoV*
 - *Gratings severely limit FoV for high energy system*