#### Coded Aperture X-Ray Fluorescence for Cargo Inspection

#### David Castañón, Clem Karl and Zach Sun

Boston University Department of Electrical and Computer Engineering

This material is based upon work supported by the U.S. Department of Homeland Security, Science and Technology Directorate, Office of University Programs, under Grant Award 2013-ST-061-ED0001. The views and conclusions contained in this document are those of the authors and should not be interpreted as necessarily representing the official policies, either expressed or implied, of the U.S. Department of Homeland Security.





## Conclusions

- Nuclear Resonance Fluorescence provides information on material properties
- Obtaining localization through collimated sensing reduces counts and makes acquisition time slow, limiting use to selective areas
- Using a coded aperture can increase SNR and lower acquisition time, but ...
- Much more to analyze secondary radiation, multispectral excitation, inverse problems, classification, system concepts & cost, ...





## Nuclear Resonance Fluorescence

- Nucleus absorbs and reemits high-energy photons (> 1MeV)
- Reemission profile vs energy is characteristic of material
- Can obtain information on elemental composition



Bertozzi, et al, 2007



## Imaging with NRF (Passport Systems)

- Use pencil beam scanning coupled with collimation to localize emission
- NRF Imager inspects localized areas of interest
- Collimation reduces signal preventing NRF from being used on a larger scale





#### Concept: Use Coded Aperture vs Collimation

- Coded mask can increase effective aperture size, photon efficiency
- Improve measured SNR to reduce acquisition time





#### Higher SNR of Coded Aperture System



Single energy, 1-D profile – Improved SNR by 1 order of magnitude

Department of Electrical & Computer Engineering

2/9/201

# Signal Inversion Approach



- Assume:
  - Emission independent at each energy
  - No photon interaction between emission and detection
  - Coding mask effect is linear, identical for each energy
  - Independent linear inversion problem at each energy



## **1-D Simulation Geometry**



## **1-D Simulation Recovered Profiles**



Data: 1000 units wide Mask: 100 units Sensor array: 1000 units, 3.9 unit res. Distance Mask to Data: 300 units Distance Sensor to Mask: 300 units





### **Two-Dimensional Reconstructions**





### **Two Dimensional Simulation**



**BU** Coded Aperture X-Ray Fluorescence Cargo Inspection

12 12/9/2014

## Conclusions

- Nuclear Resonance Fluorescence provides information on material properties
- Obtaining localization through collimated sensing reduces counts and makes acquisition time slow, limiting use to selective areas
- Using a coded aperture can increase SNR and lower acquisition time, but ...
- Much more to analyze secondary radiation, multispectral excitation, inverse problems, classification, system concepts & cost, ...



