

Metal Artifact Correction Methods for Liquid CT Scan

Xin Jin, Hui Xue, Li Zhang, and Zhiqiang Chen

Nuctech Co., Ltd

May 13, 2015

Brief Introduction

- **Application background**

- An emerging considerations of lifting the restrictions on carry-on liquids
- CT technology detects explosive materials with high reliability and accuracy

- **Problems with metallic containers**

- High density metals -> **Beam hardening effect**
- Thin containers -> **The partial volume effect (PVE)**


Result: *Unnegligible error for liquid detection tasks;*
A increase of false alarm rate.

- **Algorithms and solutions**

- Projection splitting reconstruction method
- Container edge estimation algorithm
- An attempt to over come both effects with single energy CT

- **Conclusions**

- Prior knowledge of the container helps to solve the problem
- Accurate and easy-implementing methods to discriminate objects inside metallic containers are achievable



Nuctech's CT LEDS

Background

- **Easing restrictions on carry-on liquids**

European Commission's aviation security policy:

- “a temporary restriction to be lifted when suitable technology to screen liquids for explosives became readily available”
- Goal: “a complete lifting ... as of January 2016.”

- **Benefits it brings**

- **Passenger**

- » Convenient
- » Shorter boarding time

- **Airport**


- » Less checked luggages
- » More sales revenue




Background

- **Liquid explosive detection with X-CT scan**


- X-Ray: Non-invasive inspection
- CT technique: Avoid object overlapping
- Dual-energy: Better material discrimination



Overlapped 2D image



CT image with no overlapping




Background

Dual energy CT for liquid inspection




Liquid CT scanner

Z_{eff}



Density

CT electron density image



The Problem

- Nuctech's liquid CT inspection systems

XT2080



XT2080SI



EDS+LEDS



XT2080AD




LS1516BA

The Problem

- **Metal container and image quality downgrading**

X-Ray spectrum shifts as it passes through objects (**the beam hardening effect**)

FBP reconstruction examples




Tube spectrum,
mean: 60.7keV

0.5 mm copper,
mean: 71.6 keV

1.0 mm copper
mean: 77.2 keV




water w/ steel bottle




water w/ PET bottle

Large spectrum change occurs while penetrating dense metals




CT slice (Z_{eff})
Avg. bias: **15%**






CT slice (Z_{eff})
Avg. bias: 0.8%

The Problem



- **The partial volume effect (PVE)**
 - Width of detector unit is usually larger than the thickness of container
 - Output signal is an average of each ray path
 - Beer's law is no longer well followed on edge data points



simulation of PVE




profile on real data



Method

- **Projection splitting**
 - Separate container and liquid



$$A_1 = A_{1L} + A_{1M}$$


↓

$$A_{1L} = A_1 - A_{1M}$$


Method

- **Projection splitting on real data**
 - Two dual-energy scans
 - » Above and below the liquid level
 - Requires a vertically uniform container wall

Scan configuration






Decomposition of the prior projection data
 Obtaining A_{1M} and A_{2M}



Steps of the method

Results

- Projection splitting on real data




Average of means of Z_{eff} and relative errors

Materials	Reference	Average of means		Relative error	
		Before	After	Before	After
Water	7.49	8.89	7.64	18.7%	2.0%
Alcohol	6.53	8.58	6.88	31.4%	5.4%
26% NaCl	10.90	11.61	10.72	6.5%	1.7%


Discussion

- **Advantages**
 - Easy implementation / fast computation
- **Disadvantages**
 - A uniform container wall may be required
 - Large dual-energy decomposition error



Discussion

- **The accuracy of dual-energy decomposition**
 - Error increases as p_1, p_2 goes close to two end points




Plastic container



Steel container

Method


- **A hybrid projection reconstruction method**
 - To get better separation between walls and target object
 - a more realistic physical simulation
 - » source spectrum / detector response
 - **extra prior information utilized**
 - » thickness uniformity & material information of the container



Consider the problem under a more realistic physical model ?

Realistic Physical Modeling

- **Issue 1: The partial volume effect**
 - Thickness of the container less than detector unit size
 - » can be well simulated in projection computation
 - **get a close estimation of the thickness?**
 - » parameterized description of the boundary



Assumptions:

- unified thickness of wall
- circular ring shape

Parameters:

- Center position of ring: C
- Radius: R
- Half thickness: $d0, d1$

Realistic Physical Modeling

- **Determine the parameters**


- **Hybrid projection calculation**

- » Mixed with pixels and parameterized shape

- » Mixed polychromatic and monochromatic projection

- **A optimization problem**

- » Minimize the total variation of pixel area ($\bar{\Omega}$)



Hybrid poly-/mono- chromatic projection

$$I_{\Omega+\bar{\Omega}} = \int I_0 \omega(E) \eta(E) e^{-\int (\mu_{\Omega}(\vec{r}, E) + \mu_{\bar{\Omega}, \epsilon}(\vec{r})) d\vec{r}} dE$$

Minimization problem

$$\min_{d_0, d_1, R} \|X_{\bar{\Omega}}\|_{TV}, s. t. P_{\text{forward}}(X) = P_0$$


Compute data without container

$$P_{\bar{\Omega}} = -\log(I_{\Omega+\bar{\Omega}}/I_{\Omega})$$

Realistic Physical Modeling

• Issue 2: Beam hardening


- Large spectrum shifts while penetrating metals
 - » Each projection ray has its own spectral changes
 - » Necessary correction required
 - » Simple approach: scale each projection to unify spectrum



Preliminary Result

– Edge estimation


- » Center: (0, 0)
- » Liquid radius: 3.0mm
- » Container thick: 0.4mm
- » Estimated thick: 0.409 mm
- » ISO estimation error: <0.1%
- » Thick estimation error: 2.9%




Total iterations: 200

– CT image

- » Liquid material: gasoline



Attenuation image



Discussion

- **Advantages**



- Requires only single-energy CT scan
- Capable to remove both PVE and Beam hardening effect

- **Disadvantages**

- Requires material information of the container
- A uniform thickness of the wall

- **Future work**

- Other shapes of the container wall
- Reconstruct under multiple containers/objects
- Container material estimation
- Benefits from dual-energy scan?



Conclusion

- The PVE and beam hardening effects are two major factors that influence the accuracy of liquid CT scans on metallic containers
- Additional prior information can be found to assist the CT reconstruction as well as accurate physics models
- Two methods were proposed to overcome the effects
- Better liquid CT reconstruction can be achieved

THANK YOU!

This work was partially supported by the grant from National Natural Science Foundation of China (11435007), Beijing Excellent Talents Training Foundation (2013D009004000004), and China Postdoctoral Science Foundation (2014M560092).